


More about ZSR and ZIR

1. Finding unknown initial conditions:

Given the following circuit with unknown initial capacitor voltage $v(0)$:



$$H(s) = \frac{Y(s)}{X(s)} = \frac{10s}{10s+1}$$

Simple mesh analysis yield

$$X(s) = \frac{Y(s)}{10s} + \frac{v(0)}{s} + Y(s)$$

$$Y(s) = \frac{10s}{10s+1} X(s) - \frac{10v(0)}{10s+1}$$

Immediately, we know that the transfer function $H(s)$ is

$$H(s) = \frac{10s}{10s+1}$$

and the ZSR and ZIR are respectively


$$Y_{ZSR}(s) = \frac{10s}{10s+1} X(s)$$

$$Y_{ZIR}(s) = -\frac{10v(0)}{10s+1}$$

So, if you use a step function $x(t) = u(t)$ as input, you get an exponential decay

output $y(t) = \frac{1}{2} e^{-10t} u(t)$

2. Find out about an unknown system:



How do we find an unknown system and initial conditions?

Answer: Input a test signal and measure the output. Then use the I/O relationship to figure out the system

Example: The output of the system is $Y(s) = \frac{5}{10s+1}$ for an input $X(s) = \frac{1}{s}$

So, is the transfer function $H(s) = \frac{Y(s)}{X(s)} = \frac{5s}{10s+1}$?

NO, we've forgotten the Initial Conditions!!

It should be clear that ONE pair of I/O signals will not be sufficient, we need two. Why? As we have learnt, the total output response of a system is

$$Y(s) = H(s)X(s) + \frac{C(s)}{D(s)}$$

If we have two I/O pairs, we have

$$Y_1(s) = H(s)X_1(s) + \frac{C(s)}{D(s)} \quad (1)$$

$$Y_2(s) = H(s)X_2(s) + \frac{C(s)}{D(s)} \quad (2)$$

Subtracting (2) from (1) eliminates the initial conditions and obtains the transfer function:

$$H(s) = \frac{Y_1(s) - Y_2(s)}{X_1(s) - X_2(s)}$$

The initial conditions can then be computed by substituting $H(s)$ back to (1) or (2).

Try the above example again with another I/O pairs: $X(s) = 1$ and $Y(s) = \frac{10s+4}{10s+1}$

Stability of systems

We first need to introduce the concepts of BOUNDED and TRANSIENT signals.

There are two types of well-behaved signals:

1) Bounded: $|x(t)| \leq M < \infty$ for all t .

2) Transient: $\lim_{t \rightarrow \infty} x(t) = 0$

Are these signals bounded? Are they transient?

1) $\delta(t)$

2) $\cos(t)u(t)$

3) $t \sin(t)u(t)$

4) $e^{-t}u(t)$

5) $e^t u(t)$

Answers:

- | | | | |
|--------------------|-------------|-----|---------------|
| 1) $\delta(t)$ | Not bounded | and | transient |
| 2) $\cos(t)u(t)$ | Bounded | and | not transient |
| 3) $t \sin(t)u(t)$ | Not bounded | and | not transient |
| 4) $e^{-t}u(t)$ | Bounded | and | transient |
| 5) $e^t u(t)$ | Not bounded | and | not transient |

Can you tell from their Laplace transforms?


A sufficient condition for a signal to be a transient signal :
The poles on its Laplace Transform must be on the open left half plane.

This condition is the same as saying the ROC contains the imaginary axis.

\Rightarrow the ROC contains the origin

$$\Rightarrow \int_0^{\infty} |x(t)| dt < \infty$$

$$\Rightarrow \lim_{t \rightarrow \infty} x(t) = 0$$



A bounded signal must satisfy the following two conditions:

1. Its Laplace transform must be proper.

i.e. if $X(s) = \frac{N_x(s)}{D_x(s)}$, $\text{degree}(N_x(s)) < \text{degree}(D_x(s))$

2. The poles must either be

a/ on the open left half plane or

b/ on the imaginary axis AND simple (i.e. multiplicity = 1).

Reason for Condition 1:

Consider $\delta(t)$, $L[\delta(t)] = 1$ is not proper.

For general $X(s)$, if $\text{degree}(N_x(s)) \geq \text{degree}(D_x(s))$, applying long division:

$$X(s) = a_n s^n + a_{n-1} s^{n-1} + \dots + a_0 + \frac{R_x(s)}{D_x(s)} \Rightarrow L^{-1}[X(s)] = a_n \delta^{(n)}(t) + a_{n-1} \delta^{(n-1)}(t) + \dots + a_0 \delta(t) + \dots$$

Thus, $x(t)$ is not bounded due to the delta functions.

Reason for Condition 2:

If all the poles are on the open left half plane, we know the signal decays to zero.

If there are poles on the imaginary axis, there are two cases:

Case 1: Poles are simple, i.e. multiplicity = 1 such as $L[\cos(t)] = s/(s^2+1)$. In this case, the signal is oscillating but still bounded.


Case 2: Poles are not simple, i.e. multiplicity > 1 such as $L[t\sin(t)] = 1/(s^2+1)^2$. In this case, the signal is not bounded.

Now we come back to study the stability of a system.

All systems can be classified into stable or unstable. There are three different types of stable systems.


1. Bounded-Input Bounded-Output Stable (BIBO) System
2. Asymptotic Stable System
3. Marginally Stable System

Here is a Venn diagram that describes the classification.



BIBO describes systems behavior subjected to general input, assuming zero initial conditions.

Asymptotic, marginally, and unstable systems refer to the long-term behavior of a system under any initial conditions but no input.



Recall: Given a system $H(s) = \frac{N(s)}{D(s)}$ and input $X(s)$, the most general form of output is $Y(s) = \frac{C(s)}{D(s)} + \frac{N(s)}{D(s)} X(s)$

The first term is the ZIR and the second term is ZSR.

BIBO Stability

Definition: Assume zero initial state, a system $H(s)$ is BIBO stable if it outputs a bounded output for **any bounded input**.

A BIBO system $H(s)$ must satisfy the following two conditions:

1. If $H(s) = \frac{N(s)}{D(s)}$ $\text{degree}(N(s)) \leq \text{degree}(D(s))$.
2. The poles of $H(s)$ must be on the open left half plane.

As there is zero initial condition, the output $Y(s)$ is just $\frac{N(s)}{D(s)} X(s)$. To ensure $Y(s)$ is bounded, we need to check two things:

1. $\text{degree}[\text{numerator of } Y(s)] < \text{degree}[\text{denominator of } Y(s)]$

$\text{degree}[\text{numerator of } Y(s)] = \text{degree}[N(s)] + \text{degree}[\text{numerator of } X(s)]$
 $\text{degree}[\text{denominator of } Y(s)] = \text{degree}[D(s)] + \text{degree}[\text{denominator of } X(s)]$
 Since $X(s)$ is bounded, $\text{degree}[\text{numerator of } X(s)] < \text{degree}[\text{denominator of } X(s)]$, thus all we need is **$\text{degree}[N(s)] \leq \text{degree}[D(s)]$** .

2. $Y(s)$ has either open left half plane poles and/or simple poles on $j\omega$ -axis.

As $X(s)$ is bounded, its poles must either be on the open left half poles or simple on the imaginary axis. To ensure $Y(s) = H(s)X(s)$ satisfied the same criteria, all the poles of $H(s)$ must be on the open left half plane.

$H(s)$ cannot have any pole on the imaginary axis, not even simple one because the input $X(s)$ might also have a simple pole at the same location and the resulting $Y(s)$ will have DOUBLE imaginary poles, making it non-bounded.

Asymptotic Stable

Definition: Assume zero input, a system is asymptotic stable if it gives a transient output for **ANY initial state**.

A system is asymptotically stable if all the poles of the Laplace transform $\frac{1}{D(s)}$ are on the open left half plane.

This is easy. As there is no input, the output is $Y(s) = \frac{C(s)}{D(s)}$. In general, $Y(s)$ will have the same poles as $\frac{1}{D(s)}$ unless there are cancellations of poles and zeros. Thus to ensure $y(t)$ is transient, all we need is to ensure that $\frac{1}{D(s)}$ has open left half plane poles.

Also, it is easy to see that BIBO stability \Rightarrow Asymptotic stability.

Marginally Stable

Definition: Assume zero input, a system is marginally stable if it gives a bounded output for ANY initial state.

A system is asymptotically stable if all the poles of the Laplace transform $\frac{1}{D(s)}$ are either on the open left half plane or simple on the imaginary axis.

To ensure $Y(s) = \frac{C(s)}{D(s)}$ is bounded, we need to check:

1. $\text{degree}[C(s)] < \text{degree}[D(s)]$. This is always true. See page 6-15.
2. Poles of $Y(s)$ are either on the open left half plane or simple on the imaginary axis.

Also, it is easy to see that BIBO stability \Rightarrow Asymptotic stability \Rightarrow Marginally stability.

Unstable system

Definition: Assume zero input, a system is unstable if it gives a unbounded output for some initial state.

An unstable system is a system that is NOT marginally stable.